



NOT to Scale

TOP VIEW



SIDE VIEW



In the top view layout the measurements are the actual wire lengths. The side view is the layout of how the line should run when looking at it from the side. You will have to add a little extra length at the phase line attachment point, how much will depend on how you attach the co phase line to each 4 bay. The dimensions are based on a 40" center to center if using something different just add or subtract from the center tapered section evenly on each side. The tapered line acts as a variable matching section, changing the taper, spacing, or length will change the matching. It's not a big deal it will probably just make some channels slightly better and some worse.